

MAKELSON[®]

Uninterruptible Power Supplies

USER MANUAL

BOXER SERIES

400 KVA





USER MANUAL

BOXER SERIES

400 KVA

AG-SD-98

Document P. No:1 Rev:1

About The Manual

This manual is prepared for the users of 400 kVA Boxer UPS.

Companion Manuals

For more information about this device and its options, please visit www.makelsan.com.tr .

Updates

Please visit www.makelsan.com.tr for updates. Always use the latest manuals.

CONTENTS

1 SAFETY and WARNINGS.....	4
1.1 Warnings.....	4
1.2 Clearance and Access.....	5
1.3 Storage.....	5
1.4 Shipment.....	5
2 PRODUCT DESCRIPTION.....	6
2.1 General Information.....	12
2.1.1 Static Transfer Switch	13
2.1.2 Battery Temperature Regulation.....	13
2.2 UPS's Operation Modes.....	13
2.2.1 Normal(Online) Mode	13
2.2.2 Battery (Stored) Mode	13
2.2.3 Bypass Mode	14
2.2.4 Automatic Restart Mode.....	14
2.2.5 Maintenance Mode.....	14
2.3 Battery Management.....	14
2.3.2 Advanced Level Functions (Automatic Battery Test)	15
2.4 User Panel.....	16
2.4.1 Opening Screen	18
2.4.2 Main Menu.....	18
2.4.3 Navigating Through the Menus	18
2.4.4 Password Protected Menus	19
2.4.5 Control Menu	19
2.4.6 Status Menu	20
2.4.7 Setup Menu	21
2.4.8 Logging Menu.....	24
2.4.9 Service Menu.....	24
3 INSTALLATION.....	25
3.1 Single Module Installation	25
3.1.1 Warnings.....	25
3.1.2 Pre-Installation Check Up	26
3.1.3 Positioning	26
3.1.3.1 Positioning the UPS	26

3.1.3.2 Placing External Batteries	27
3.1.4 Transportation Type of Cabinets	28
3.1.5 Mains, Load and Battery Connections	28
3.1.5.1 External Protections	28
3.1.5.2 Cable and Fuse Configuration	29
3.1.5.3 Cable Connections.....	30
3.1.5.4 Connecting Batteries	33
3.1.5.4.1 External Battery Installation Procedure and Connection	33
3.1.5.5 Control and Communication Cable Connections.....	35
3.2 Parallel Setup	36
4 OPERATION	39
4.1 Operation Procedure	39
4.1.1 Circuit Breakers	39
4.1.2 First Start-Up.....	40
4.1.3 Testing the Operation Modes of the UPS.....	42
4.1.3.1 Switching from Normal Mode to Battery Mode.....	42
4.1.3.2 Switching from Normal Mode to Static Bypass Mode.....	43
4.1.3.3 Switching from Static Bypass Mode to Normal Mode.....	43
4.1.3.4 Switching from Normal Mode to Maintenance Bypass Mode.....	44
4.1.4 Performing a Complete Shutdown.....	46
4.1.5 EPO(Emergency Power OFF)	47
4.1.6 RS232 Serial Communication Installation and Examination	47
5 EXPLANATIONS of LOGGING.....	48
6 TABLE of TECHNICAL SPECIFICATIONS	53
7 GUARANTEE.....	55
7.1 Terms of Guarantee.....	55
7.2 Cases Not Covered by the Guarantee	56
8 CONTACT INFORMATION	61

1 SAFETY and WARNINGS

1.1 Warnings

This manual must definitely be read and understood before installing the UPS. The installation and first start-up can be performed only by an authorized MAKELSAN staff.

Installation and start-up by unauthorized persons may cause serious injury and/or result in death.

The UPS is designed to be used in continuous vertical position in fixed-positioned applications.



THE UPS MUST BE USED WITH GROUND CONNECTION.

Connect the ground cable before connecting the mains.

The ground leakage current may rise up to 0,4A.



THE UPS MUST BE DISCONNECTED FROM THE MAINS AND BATTERIES BEFORE SERVICING. ALSO, FOR SERVICE AND MAINTENANCE, WAIT FOR AT LEAST 5 MINUTES FOR THE DC BUS CAPACITORS TO DISCHARGE AFTER POWER OFF.

Service-Maintenance

All service and maintenance operations are performed internally. All parts of UPS can be serviced and replaced only by a trained technician.



Performing regular protective maintenance at least once a year is recommended beginning from the first installation. (This service will be provided for a fee by our authorized staff.)



BATTERY VOLTAGE MAY RISE UP TO 450 VDC!

Battery voltages are in deadly levels (450Vdc). Batteries must not be touched except the trained staff. Batteries certainly must not be thrown into fire. Regarding the topic of batteries which are dead and defected: The waste batteries must definitely not be thrown to nature. They must be delivered to MAKELSAN authorized technicians or to the foundations which are authorized for collecting waste batteries by the Ministry of Environment.

Fire extinguishing equipment must be kept nearby the UPS for electric fires.

1.2 Clearance and Access

Clearance

There exist no air inlet or exit at the back of 400 kVA UPS devices. The air is taken through front and side. It is evacuated through fan grids on the top side. There must be 1200 mm clearance at least at front side to open the front cover of UPS and at least 1000 mm clearance at the back of the UPS. There should not be permanent or temporary use within the limits specified. Otherwise, the UPS's performance will decrease.

Access

Operator can reach the UPS through all sides on our products in the range of 400 kVA. Therefore, enough area must be left for operator. Recommended clearance is 600 mm at least.

1.3 Storage


The UPS should be kept in a room or area where is protected from excessive moisture and heat before commissioning.




Unused batteries must be charged at regular intervals. This time interval is determined by the battery supplier. Charging batteries can be performed periodically by connecting to a proper mains for a while.

1.4 Shipment

Carrying vehicles or handling accessories must have enough features and characteristics to carry UPS's weight.







Move the UPS as rarely as possible.

2 PRODUCT DESCRIPTION

General View




Front View


BX400EN003R0

1	320x240 6" Graphic LCD
2	Fresh Air Vacuum Grid
3	EPO (Emergency Power Off) Button
4	Menu Navigation Keys
5	Mimic Diagram

Front Cover View




1	RS232 Serial Communication Socket and Optional Slot
2	Soft Start Button
3	Mains Circuit Breaker
4	Input Terminals
5	Neutral Terminals
6	Mechanic Bypass Circuit Breaker
7	Ground Connection
8	Battery Circuit Breaker
9	Battery Terminals
10	Output Terminals

Top and Rear View

1	Wiring Hot Air Evacuation Channel
2	Parallel Connecting Socket Mount Point
3	Fresh Air intake Channel


Electrical Connections



2.1 General Information

General operation topology of Boxer Series devices can be recognized as follows:

MAKELSAN® Electrical Topology of Boxer Series UPS



The UPS gets the energy through the CB1 breaker. The rectifier starts working after energy fills the DC bar capacitors. The rectifier converts the AC mains to DC voltage and charges the batteries in a controlled manner. When there is no power from main the power is drawn from batteries to produce the sufficient DC Bar voltage. DC voltage is converted to mains synchronized AC voltage by the inverter. This is a high quality voltage. Generated AC power will be applied to the loads through the static semiconductor transfer switches and output (load) circuit breakers.

When maintenance or repair are needed, before input (CB1) and output (CB3) circuit breakers are taken to the open circuit (OFF) position, switch the UPS from normal mode to static bypass mode (see 4.1.3.2). Secondly, the maintenance circuit breaker (CB2) is taken to the closed circuit (ON) position and afterwards, firstly output (CB3), consequently and input circuit breakers (CB1) are taken to the open circuit (OFF) position respectively.

2.1.1 Static Transfer Switch

Some blocks are named as static switches as can be seen above. These blocks consist of inverse parallel connected thyristors. These switches, which are under the control of the main board control unit, provides controlling of feeding the loads through either bypass or inverters. The loads are fed through inverter during the normal operating mode. Therefore, inverter static switches are active if there is no problem with the system.

System provides the loads to be fed smooth and seamless by bypass or inverter. In order to manage this process at minimum risk, UPS synchronizes the inverter output and mains bypass as the same phase and frequency. Therefore, inverter frequency is the same as bypass frequency as long as it is acceptable within frequency limit.

User can switch between mains and inverter, using the front panel. The UPS, operating from the mains with user instruction, will automatically undertake the load in the event that the mains cuts off or is out of tolerance.

2.1.2 Battery Temperature Regulation

Temperature sensor is provided in external battery cabinets. Temperature of batteries is measured by this sensor. The UPS adjusts charge parameters according to the information of the detected temperature.

2.2 UPS's Operation Modes

Boxer series UPS's on-line and has a double loop structure. Our products operate in the following modes:

- Normal (Online) Mode
- Battery Mode
- Bypass Mode
- Auto Restart Mode
- Maintenance Mode

2.2.1 Normal(Online) Mode

In this mode, the UPS supplies the load through the inverters. Rectifier unit is fed by the AC mains. Inverter and battery charger units are fed by the generated DC supply.

2.2.2 Battery (Stored) Mode

In case of any failure of the mains, while the UPS is feeding the critical loads through inverter, this energy is supplied by the batteries.

2.2.3 Bypass Mode

On account of UPS overload or any problem on inverter, no qualified AC output is produced and if bypass voltage and frequency are in tolerance, loads are then fed through bypass source. UPS switches from inverter to AC source via static transfer switches without any interruption. The inverter source and bypass must be synchronized in order to manage this switching processes without any problem. If inverter output and mains are not synchronized, this switching may take up to 15 msec. varying according to load type.

2.2.4 Automatic Restart Mode

In case of any failure of the mains, the UPS will continue feeding the critical loads until the batteries reach the end of discharge voltage level. The UPS will go on working until the batteries are drained, and then will shut down. After the mains conditions get back to normal, the UPS automatically starts to operate in a period to be determined. In this case, the UPS continues to operate in normal mode as long as the mains values are in desired criteria. In the Boxer SERIES UPS, this feature is not activated in factory settings.

2.2.5 Maintenance Mode

The UPS is equipped with a specific protection switch in order to keep the loads powered during maintenance. This switch is designed so as to handle UPS loads completely.

2.3 Battery Management

Constant Charge Current

Constant current as 1/10 rate of the battery capacity is applied to battery, until it reaches the float voltage.

Float Charge

Depending on the battery discharge current, 1/3 of the energy of the battery is charged at this level. Owing to this level, batteries are kept ready for use at the highest capacity. For lead-acid batteries, this voltage varies between the values of 2.2-2.35 V/cell. This voltage may differ slightly due to temperature adaptation. Option of setting this coefficient is provided with our UPS. If the temperature sensor is used, it is recommended to use.

Deep Discharge Protection

While the system is operating in the battery mode, if battery voltage has dropped below the deep discharge voltage level, the UPS shuts down and stops absorbing energy from the batteries. This value varies between 1.6-1.75 V/cell for Lead-Acid batteries, and between 0.9-1.1 V / cell for Ni-Cd batteries.

Low Battery Warning Level

While the system operates in spare, in other words, battery mode, if the battery capacity drops below its 40% value with actual loads, it will give audible and visible alarms. This value can be adjusted by user between 20%-70%.

2.3.2 Advanced Level Functions (Automatic Battery Test)

The auto battery test automatically discharges 10% of the battery existing capacity in a certain period defined (default is 90 days). The period between two tests can be adjusted by user between 30-360 days. At the end of the test, one of these two status, “**good or replace**” is determined.




At the end of this test, if batteries are reported as “replace”, then the batteries are completely drained after the test. In this case, loads can remain unpowered in case of mains power off.

This test can automatically be started by command from front panel monitor, via telnet interface, via RS232 smart communication or via UPSMAN (SNMP, see the options).

As a result of all these tests, it is checked whether the batteries that are presently used can supply the minimum needs of loads in case of the first power-off or not. It is recommended that test results be checked at regular intervals.


2.4 User Panel


User panel consists of mimic diagram, LCD screen, EPO button and menu keys. The device can be controlled via this panel.



1	Rectifier indicator LED It constantly illuminates when rectifier works.
2	AC/DC module (Rectifier)
3	Battery discharge indicator LED It illuminates in battery mode and flashes when UPS is started up through batteries.
4	Battery charge indicator LED It illuminates while the batteries are charged.
5	Battery module
6	DC/AC module (Inverter)
7	Bypass static switch indicator LED It illuminates while the loads are fed through bypass line.
8	Inverter static switch indicator LED It illuminates when the load is fed by the inverter.
9	Alarm/Warning indicator LED
10-13	Menu keys
14	EPO Button

Menu Flow Chart






2.4.1 Opening Screen

When the front panel monitor is turned on, firstly opening screen is observed. Manufacturer – Model Name, Date – Time, Load Status as Percent, Battery Charge Status as Percent, Remaining Back up (Autonomy) Time, Device Mode – Actual Alarms, Main Menu Titles can be observed here. In case of an alarming condition, alarms are shown on the left-down row. If no button is pressed for 5 minutes,


system returns to the opening screen.



2.4.2 Main Menu

Switch from opening screen to the main menu through ENT button.

2.4.3 Navigating Through the Menus



Press UP/DOWN keys to move the cursor arrow in the screen.

Open a sub-menu with ENT button, go back to the previous menu with ESC button.


Control sub-menu is shown on left.

Some menus consist of more than one page.

Switch among the pages with UP/DOWN buttons.

Some menus have changeable options like ON/OFF, durations or quantities. To change setup in such menus, choose variable with ENT, set new value with UP/DOWN buttons and save it with ENT button. Cancel with ESC button.

2.4.4 Password Protected Menus



Some menus such as the control menu are password protected. To enter password choose each digit with UP/DOWN buttons and confirm with ENT button.

User level password is: 0000

2.4.5 Control Menu


The followings can be done in the control menu:

- | | |
|--------------------------------|-------------------------------|
| ➤ Start | Start the UPS. |
| ➤ Stop | Stop the UPS. |
| ➤ Switch to BYPASS | Switch to static BYPASS mode. |
| ➤ Switch to UPS | Switch to online mode. |
| ➤ Battery Quick Test | Start the quick battery test. |
| ➤ Battery Capacity Test | Start the deep battery test. |
| ➤ Stop Battery Test | Stop the battery test. |

Battery status test, drains the 10% of battery energy and reports batteries which has more capacity than 10% as **“Good”**, less capacity than 10% as **“Replace”** according to the test results.

After the device is started and every 24 hours, it automatically performs a quick battery test, if test counter value is zero.

Note: Batteries must have been fully charged and kept in floating situation for 1 hour before performing the quick battery test.



Batteries must have been fully charged and kept in floating situation for 5 hour before performing the battery status test.

Battery tests are performed by directing the power to the mains, independently from the loads. If the mains values get out of limits during the test, test is cancelled.

Following **Status> Battery** menu, how many minutes left to start the test can be observed.

If **"Stop Battery Test"** is chosen from the menu, the device cancels the battery test and goes back to the previous operating state.

2.4.6 Status Menu



You can see information about the mains, output, bypass line, battery, temperatures, inverter, alarms and device information on this menu.

Mains

UP, F, I, UL Frequency, current and voltage (phase-neutral, phase-phase) of each phase.
S, P, PF Apparent power, active power and power factor of each phase.

Output

UP, F, I, UL Frequency, current and voltage (phase-neutral, phase-phase) of each phase.
S, P, PF Apparent power, active power and power factor of each phase.
L, CF Load as percentage and crest factor of each phase.

Bypass

UP, F, I, UL Frequency, current and voltage (phase-neutral, phase-phase) of each phase.

Battery

Mode Operation Mode of the device.

U, I, °C Charging voltage, current and temperature.

Charge% Charge percentage.

Autonomy Time Remaining back-up (autonomy) time

Last Test Result Capacity and status according to the last test results

Next Test Date Next test date, time and remaining time for test

Temperature

°C, °C, °C, °C, °C Rectifier, inverter, ambient, battery bypass and thyristor temperatures.

Inverter

U, I, P Voltage(phase-neutral), current and active power of each phase.

Alarms

Alarms Actual UPS alarms.

Device Information

___-___-___-___ Inverter, rectifier, CPLD, front panel software version.

----- UPS serial no.

KVA, V/Hz Apparent power, instantaneous output voltage (phase-neutral), instantaneous output frequency.

x Ah Parallel battery arm number x Serial battery arm number Battery capacity adjusted in UPS.

2.4.7 Setup Menu

The following settings can be performed via setup menu:

**Date & Time**

To set date and time, use up and down keys to choose the variable you want to set and press ENT.

Set the value via arrow buttons and press ENT button again.



Battery Installation Date

When new batteries are installed, set the battery install date via this menu.



Automatic Restart


In battery mode, the device operates until batteries discharge and then shuts down. Auto-restart can be used to restart the UPS automatically when the mains gets back into limit values.

Open/close auto restart via the option of ON/OFF and determine how much time after the device will be option below.



Automatic Battery Test

Use this menu to open/close automatic battery test and to set the period (repeat period for the regular test) independently from user.



Screen


Change the screen contrast setting to make it more visible on different environmental conditions.

**Beeper**

Turn the beeper sound on/off.

**Language**

Set the menu language.

**Communication**

Set the protocol for the RS232 connection. The options are SEC and Telnet.

MAKELSAN BOXER 18/07/2012 16.22:47 400KVA 3/3 SINGLE	
18/07/2012 16.15:18 E001 <----- Batteries Changed	Control
18/07/2012 16.08:22 E002 Ambient Abnor. Temp.	Status
18/07/2012 16.08:22 E003 EPO key pressed	Setup
	Logging
	Service
18/07/2012 16.15:18	No Alarm
Normal Mode	

2.4.8 Logging Menu

he last 500 logs can be observed in the logging menu.

While observing any of the logs, if ENT button is pressed, all details regarding the moment of the event (mains, bypass, output values, alarms etc.) can be seen.

Older/actual logs can be observed, using UP/DOWN buttons.

MAKELSAN BOXER 25/07/2012 13.03:20 400KVA 3/3 SINGLE	
25/07/2012 11.13:51 E004 <----- Normal Load	Control
25/07/2012 10.50:50 E005 Over Load	Status
25/07/2012 10.49:02 E006 Bypass Mode	Setup
	Logging
	Service
25/07/2012 11.14:34	No Alarm
Normal Mode	

2.4.9 Service Menu

MAKELSAN BOXER 18/07/2012 16.12:47 400KVA 3/3 SINGLE	
Password	Control
0***	Status
	Setup
	Logging
	Service
18/07/2012 16.08:22	Alarms
Normal Mode	

Service menu is password protected.

It can be accessed by authorized service staff.

3 INSTALLATION

3.1 Single Module Installation

In this section, warnings which you must follow and the checks which you must perform before starting-up the device are stated. Additionally, you can find information concerning the points you must pay attention to during carrying style for cabinets, positioning and connections.

3.1.1 Warnings



The UPS must be installed by the staff approved by MAKELSAN. Do not energize a UPS not properly installed. The device installed and energized without staff approved by MAKELSAN is not covered by warranty.



Battery Hazard!

In some models, during operation of battery and the UPS together, there may exist battery terminal voltages reaching up to 450 VDC.

Precautions must be taken in order to protect eyes against electrical arcs that can result from contacts.

ESD-protected rubber gloves should be used.

Batteries discharging or leaking electro liquid must not be used, if any, it must be replaced. Uninstalled batteries must be kept, carried and transferred to destruction points safely.

In case of skin contact with elector liquid, immediately rinse the exposed skin part with water.

Operator must remove any dangerous accessories such as ring, watch etc. before working on the device.

The product needs three phase and four cable (+ground) supply system for input. Type of this supply system conforms to IEC60364-3 standards. The devices have transformers which have ability to optionally convert from three cable to four cable system. Provided that IT AC power distribution will be installed, 4 pole-circuit breaker must be used. More detailed explanations concerning the topic can be found in the standard named as IEC60364-3.

3.1.2 Pre-Installation Check Up

Before installing the UPS product, the following checks should be carried on. These are the first and important steps in the operation of the product correctly.

- Definitely check whether or not there is any damage to internal and external structures of the UPS, accessories and batteries during transportation or shipment. Report any damages before receiving.
- Make sure that the product is the right model. Check whether the label in front the device matches with the product ordered.

3.1.3 Positioning

The UPS and the batteries are designed for indoor use, and must be placed on an area with cool air flow.

3.1.3.1 Positioning the UPS

For the Boxer 400KVA Series, fresh and cool air enters the device from the front and rear sides and evacuated through the fans on the top of the device. Air entrance and exit points should never be closed. It must be positioned on a place where is protected from water or similar liquid contact risks.

If the area is very dusty, filters optional provided must be used. Usage of these filters must be performed according to the relevant instructions.

The UPS is structurally a losing-energy system. Lost energy occurs as temperature. How forced air cooling system is needed is provided in the following table. Using the table, what capacity of air conditioned should be used to cool the place where the UPS is can be determined.

Device Rating	BTU/h amount for cooling	Estimated BTU/h value For 100%Bridge Load (Non-Linear Load)
400 KVA	87500	104900

3.1.3.2 Placing External Batteries


Batteries should be mounted in an environment where the temperature is consistent and even over the whole battery. Temperature is a major factor directly affecting the battery life and capacity. In general, battery manufacturers recommend that batteries be used in 20-25 °C. Furthermore, battery manufacturer companies indicate the performance of batteries according to the said temperature range. If the temperature exceeds the said range, the life of the battery will decrease. On the contrary, again if the temperature drops the said range, the capacity of the battery will seriously decline. Therefore, expected time will not be obtained during back up. As a result, keep batteries away from heat sources and serious air flows. Pay attention to the said factors and be careful about and observe the following points in terms of external connections of the batteries:

- Keep batteries away from main heat sources.
- Keep batteries away from serious air flows.
- Keep batteries away from the humid places. Hereby batteries can be prevented from terminal oxidations and possible leakage currents.
- Please use aR or gR semi-conductor type fuse at the battery rooms and cabinets.
- If it is possible, please use breaker switch without fuse for the battery cabinet.
- Keep battery cabinets and shelves high above the ground. UPS should be protected against possible floods or liquid contacts.
- Battery rooms should be properly ventilated.
- Shelves will be accessible in touch if batteries are in battery room. Therefore, please keep restricted accessing to battery rooms. Use necessary safety writings and strips.

Especially, for the external cabinet batteries system of UPS, fuses must definitely be used. These fuses must be mounted as close as possible to the batteries. This closeness will increase the electrical operation safety with the battery.

BOXER EXTERNAL BATTERY CABINET CONFIGURATION	
Device Rating (kVA)	400 KVA
Batteries in series	31
Independent Group Number	2
Total number of Battery	62
I_{charge_max@V_{bat_max}}(A)	95
I_{bat_max@V_{bat_cut off}}(A)	523
Recommended external cabinet fuse (A)	800

External battery cabinets and battery room applications are given below as an example. The application form may vary according to the customer.



Example Battery Chamber Application

3.1.4 Transportation Type of Cabinets

Pay attention that carrying vehicles or handling accessories must have enough features and characteristics to carry the weight of the UPS.

The UPS and optional battery cabinets are designed to be carried by a forklift or similar vehicles.

Be more careful of sudden movements, especially when batteries are inside of cabinet.
Move the UPS as rarely as possible.

3.1.5 Mains, Load and Battery Connections

Distribution board is recommended for the UPS outputs. Load protection fuses and breakers must be used in such distribution board. Additionally, fuses with various speeds may be needed according to load. A-B type fuses or magnetic breakers are recommended to be used if the load is suitable.

3.1.5.1 External Protections

To protect the AC inputs, thermal magnetic breakers or V-automat breakers must be independently installed on the distribution board. Herein, the cable intersections and fuse values must be determined and connected by an expert authorized person.

Over current protecting must be installed on mains input board. This protection must be selected in conformity with the bearing capacity of over current and over load of the UPS. The fuses in the board must be chosen as 135% higher rated than the current values given in the table below, and the fuses must be C-type (slow).

Ground leakages flow to the ground through the EMI filters on the input and the output of the UPS. Accordingly, MAKELSAN recommends residual current relay over 300mA.

The residual current relays to be placed in the UPS input must also be:

- ✓ Resistant to both positive and negative DC pulses,
- ✓ Not sensitive to transient currents.
- ✓ Must be sensitive to currents which is average between 0, 3-1 ampere.

3.1.5.2 Cable and Fuse Configuration

Cable designs must be compatible to current and voltage values stated herein, additionally local instructions must be obeyed about these topics.

UPS Rating (KVA)	Rated Currents (A)					
	Mains Currents at Maximum Battery Charge (3 phase + neutral)			Output Currents under Full Load (3 phase + neutral)		
	380V	400V	415V	380V	400V	415V
400	725	688	664	606	576	555

Non-linear loads (loads such as computer) may affect cable section design. Their neutral currents might be more than phase currents, even may rise up to 1.5 times the phase current.


Each cabinet must be, directly and as short as possible, to ground line by means of protection ground cable. Typical ground cable cross sections are 185 mm² for 400 kVA. It is recommended that cable length not exceed 5 meters.

3.1.5.3 Cable Connections

UPS input, output and battery connection inlets are made from the front side of the UPS.




ATTENTION! 3 pole-circuit breakers (switch) are used for the input and output of the UPS, Neutral line is not interrupted.




1	Input Terminals
2	Neutral Terminals
3	Battery Terminals
4	Output Terminals
5	Neutral Terminals

Please, follow the steps below for electrical connections:


1. Switch all the breakers in the distribution boards to open circuit (OFF) position and make sure that loads and the mains are isolated from cables.



2. Connect the ground cable.




3. Make sure that all the circuit breakers are in the open circuit (OFF) position. Use of breakers are explained in the following sections.



BX400EN011R0

4. Connect the input cables:

- R phase to input L1,
- S phase to input L2,
- T phase to input L3,
- N(Neutral) to Input N.



BX400EN012R0

5. Check the phase sequence.

6. Repeat steps 4 and 5 for output connections and external bypass input.

Use the cable clips to stabilize the cables when the connections are done.



Make sure that the loads in the output of the UPS prepared are isolated during the connection if they are not ready to be connected yet.



Before the UPS is started, make sure that cable connections have been made in accordance with the warnings in boards. Additionally, check if there is isolated transformer at the input of UPS and consider the local directions.



Make sure that grounding has been made properly. Wrong works or grounding made may damage the UPS and other systems in the installation.

3.1.5.4 Connecting Batteries

You can find explanations about installation procedures and connections of internal and external batteries in this section.


3.1.5.4.1 External Battery Installation Procedure and Connection

You can find details about how to configure the external batteries under “External Batteries Configuration” title above. The information about connection of external batteries and UPS is given in this section.



Avoid short circuiting batteries. Exploding batteries can damage you and your environment!
Battery terminal may rise up to 450 Vdc!


1. Switch “CB4” breaker on the UPS to the position of open circuit (OFF).
2. If there is, switch breakers on the battery cabinet to the position of open circuit (OFF).
3. Remove the battery fuse on the battery cabinet.
4. Remove battery fuse on the UPS.



5. Make sure of serial and parallel connections of external battery packs are correct.
6. Connect the cable to terminals of one of the UPS, "N" (Battery Neutral)", one "+BAT" and one "-BAT" respectively.
7. Connect four cables that come from UPS to terminals on external battery cabinet or in battery room according to external battery connection diagram below. As follows:

➤ "+ BAT"	←-----→	Positive Battery Group "+" terminal
➤ N(UPS)	←-----→	Positive Battery Group "-" terminal
➤ N(UPS)	←-----→	Negative Battery Group "+" terminal
➤ "-BAT"	←-----→	Negative Battery Group "-" Terminal


8. Make sure that the polarities are connected correctly by checking battery connections for the last time.
9. Replace battery fuse on UPS.



10. Replace battery fuse on battery cabinet.
11. If there is, switch breakers on the battery cabinet to the position of closed circuit (ON).
12. Check if there is appropriate battery voltages to the battery input terminals of the UPS by means of a proper measuring device.

External battery cable selection is determined by application. Fuses which are recommended for the UPS and battery cabinet are given. To connect to these type fuses, the lowest diameter cables are suggested. Please, refer to the standard called EN 50525-2-31(VDE 0100-430) in this subject. The selection should be such that the cable will allow at most 0.5 Vdc decreasing.

There exists "**External Battery Temperature Measurement Kit**" to provide optimization of the batteries according to battery temperatures in the external battery cabinet application. Thus, battery charge temperature can be optimized according to the temperature.



BX400EN013R0

3.1.5.5 Control and Communication Cable Connections

MAKELSAN UPS have standard or optional connections of advanced external battery cabinet, environmental monitoring, control panels and various intelligent monitoring.

Connections of the front side of UPS:

- One RS232 serial communication bus (RS232/Inverter Service)
- Two optional card slots

Connections at the top of UPS:

1. One paralleling connection socket(optional)


3.2 Parallel Setup

The product which you have bought can be operated in parallel; however, this feature is offered as an option. Please contact your authorized vendor for parallel operation.



Parallel application should be made by authorized personnel assigned by MAKELSAN!

In case of need of redundancy or more power, Boxer series UPS can be operated in parallel up to quantity 8. A principle scheme which shows a system in which two UPS are connected in parallel is given below:




Input and output of more than one device are connected to each other; but definitely each battery group is different from another, batteries cannot be used in common. The following points should be considered while placement of devices in parallel system and their electrical connections are made:


- The devices which are connected in parallel must be from the same series and must have the same rated power.
- Devices must be running on the firm ware with the same version and revision codes, devices operating with old firm ware must be updated.
- Devices must be located as close possible as to each other (maximum 6 * 110 cm paralleling cables.)
- Each device must have its own neutral cable.
- Each device must have its own ground cable.
- Devices must be connected through the distribution board and phases must be properly connected. ($U_1-U_2-...-U_N$), ($V_1-V_2-...-V_N$), ($W_1-W_2-...-W_N$).
- Same battery group must not be connected to devices more than one
- For equal current sharing, all cables with which the devices are connected to the board must be equal in length and cross section.

Parallel Settings

Connect the parallel cable as shown in figure below. Only use the cables provided by MAKELSAN.



Software settings on the user panel should be made by authorized personnel.



4 OPERATION

4.1 Operation Procedure

You can find information about circuit breaker, first start-up, types of UPS operation tests, turning UPS off, EPO and RS232 serial communication system in this section.

4.1.1 Circuit Breakers

The UPS has four circuit breakers accessible from the front side. These are used for the AC input, maintenance bypass, output and the battery connections respectively.

Three-phase AC voltage is applied through **CB1** to input of UPS.

AC input voltage will be applied directly to loads through **CB2**. In this way, maintenance purposed switching is done properly.



WARNING: If CB3 is in the closed circuit (ON) position and UPS is working at on-line mode, before CB2 is taken to the closed circuit (ON) position, the UPS must definitely be switched to static bypass mode.

CB3 is used to connect or separate AC voltage that come from static switches to the loads on UPS.

External batteries are connected to UPS through **CB4**.


Active Breakers	Operation Mode	Explanation
CB1, CB3, CB4	Normal Mode	UPS operates in normal mode.
CB3, CB4	Static Bypass Mode	UPS is overload, loads will be transferred to static bypass line temporarily.
CB2	Maintenance Mode	UPS is shut down for maintenance, maintenance is supplied through bypass.

4.1.2 First Start-Up



Wait at least 5 seconds between each step.


1. Switch all the breakers to open circuit (OFF) position.
2. Push the Soft Start button (SW1) for 10 seconds at least.
3. Switch the input breaker to (CB1) position.




4. Start the UPS using the front panel.

Main Menu>Control>Password>Start






5. Check the device has switched to normal operation mode, via front panel display led indicators and LCD panel.



6. Switch battery circuit breaker (CB4) to closed circuit (ON) position.

7. Switch output circuit breaker (CB3) to closed circuit (ON) position.



BX400EN017R0

8. You can turn on the loads connected to the device.


After all these steps, check that load is fed through inverter static switches via mimic diagram. In a contrary situation, check UPS total and phase loads. The UPS gives audio alerts in an overload condition, without feeding critical AC loads.

4.1.3 Testing the Operation Modes of the UPS

After first start-up, switch among operation modes with the aim of control.

4.1.3.1 Switching from Normal Mode to Battery Mode


Switch CB1 to open circuit (OFF) position. This action cuts off the mains voltage and the UPS starts operating on battery mode. After checking the operation, switch CB1 to closed circuit (ON) position again.



4.1.3.2 Switching from Normal Mode to Static Bypass Mode

Switch the UPS to bypass mode via user panel. Check if static bypass led has flashed in mimic diagram.

Main Menu>Control> Switch to BYPASS




Note: The UPS will not switch to bypass mode if the mains is out of limits or phases are wrongly connected.

4.1.3.3 Switching from Static Bypass Mode to Normal Mode

Switch the device to UPS mode via user panel. Verify the case through mimic diagram.

Main Menu>Control> Switch to UPS



Note: The inverter will not undertake the load if the inverter voltage is out of limits or there is overload or over temperature situation.


4.1.3.4 Switching from Normal Mode to Maintenance Bypass Mode




Make sure that the inverter output is synchronous with the maintenance bypass line before switching to maintenance bypass mode. Otherwise, there is a possibility of cutting off the load power for a short while.

Switch the device to static bypass mode using the front panel. Check the mimic diagram to make sure that static bypass led has flashed or not.

Main Menu>Control> Switch to BYPASS



1. Switch CB2 to closed circuit (ON) position.




2. Stop the UPS using the front panel.

Main Menu>Control >Password>Stop



3. Switch CB1, CB3, CB4 breakers to open circuit (OFF) position.



FOR SAFETY, WAIT 5 MINUTES AT LEAST BEFORE OPENING UP THE DEVICE AFTER YOU HAVE SWITCHED THE DEVICE TO THE MAINTENANCE BYPASS MODE.

4.1.4 Performing a Complete Shutdown

1. Turn off the loads connected to the device.
2. Stop the device using the front panel.

Main Menu> Control> Password> Stop




3. Check if the UPS has switched to bypass mode, via LED indicators and LCD panel in the front panel.
4. Switch the output (CB3), battery (CB4) and input (CB1) to open circuit (OFF) position respectively.



MAKE SURE THAT THERE ARE NO CRITICAL LOADS ON THE UPS OUTPUT BEFORE PERFORMING A COMPLETE SHUTDOWN

4.1.5 EPO(Emergency Power OFF)

By pressing the EPO button, the UPS turns the rectifier and the inverter off respectively. If the output breaker turn off option is also set, the UPS completely disconnects from the system.



BX400EN021R0

4.1.6 RS232 Serial Communication Installation and Examination

Boxer series has an RS-232 interface which supports SEC and TELNET protocol as standard. This interface is fully isolated and safe. The status of UPS can be monitored remotely via a PC or SNMP by using this protocol. This connection works with any kind of option.

5EXPLANATIONS of LOGGING

The UPS will beep when any problem is detected. You can see the first information about the situation on the mimic status membrane. This may not be enough most of the time. In this case, you can see the following warnings by making use of log screen.

	Event	Explanations of Events
1	RS232 Start Command	UPS was started by RS232 communication software.
2	RS232 Stop Command	UPS was stopped by RS232 communication software.
3	Auto Restart	After the batteries discharge totally, UPS restarted itself automatically after the mean time which adjusted that follows the mains getting back to normal values.
4	UPS Startup	The main board of the UPS is energized.
5	Bus not Charged	UPS could not charge its bus to the desired value.
6	Quick Battery Test	Quick battery test has begun.
7	Deep Battery Test	Battery capacity test has begun.
8	Battery Self -Test	Periodical battery test has begun.
9	End Of Discharge	Batteries' voltage has gone below cut off voltage value while UPS was operating on the battery mode.
10	Overload Timeout	UPS has operated at overload more than time limit adjusted. The Loads will be transferred to bypass line.
11	End of Battery Test	Battery test has completed. Details concerning test results can be monitored via the battery status menu.
12	Battery Test Aborted	Test was aborted manually or by UPS since the criteria were not provided during battery test.
13	Manuel Switch To BYPASS	Static switches directions were changed manually to the bypass line via UPS command menu.
14	No Battery	UPS detected that no battery exists during operation.
15	Maintenance BYPASS Switch On	Maintenance bypass switch has been activated.
16	Abnormal Ambient Temperature	UPS operating ambient temperature exceeded the permitted limits.
17	Inverter Over Temperature	Inverter's temperature is out of limits, in the event of 5 degrees increment more, the load will be transferred to Bypass line.
18	PFC Over Temperature	Rectifier's temperature is out of limits, in the event of 5 degrees increment more, the load will be transferred to Bypass line.
19	STS Over Temperature	Static transfer switches' temperatures are out of limits. UPS will be stopped.
20	Output FL1 Over	Short circuit protection is activated for output L1 phase.

	Current	
21	Output FL2 Over Current	Short circuit protection is activated for output L2 phase.
22	Output FL3 Over Current	Short circuit protection is activated for output L3 phase.
23	Bypass Voltage Bad	Bypass voltage value is out of limit while UPS was operating on the bypass mode. UPS will switch to normal mode if temperature and load status are normal, but if not, UPS will stop.
24	Bypass Frequency Bad	Bypass frequency value is out of limit while UPS was operating on the bypass mode. UPS will switch to normal mode if temperature and load status are normal, but if not, UPS will stop.
25	Coil Over Temperature	Over temperature is observed in UPS inverter or rectifier coils.
26	Inverter Voltage Bad	Inverter voltage limit values are exceeded. The load will be transferred to bypass line, when inverter voltage gets back to normal values, UPS will switch to normal mode again.
27	Overload	Output load value is over %105, overloading counter will start to count, If UPS is on normal mode, charging will be stopped until load value gets back to normal.
28	Maintenance BYPASS Switch Off	Maintenance bypass switch is deactivated.
29	Normal Ambient Temp.	UPS ambient temperature has got back to allowed limit values.
30	Normal Mains Voltage	Mains voltage is in the limited values, UPS will switch to normal mode.
31	Normal Inverter Temperature	Inverter temperature is in the limited values. If load and other temperature values are normal, UPS will switch to normal mode.
32	Normal PFC Temperature	Rectifier temperature is in the limited values. If load and other temperature values are normal, UPS will switch to normal mode.
33	Normal Charger Temperature	Charger/booster module temperature is in the allowed limits, charging will be activated again.
34	Normal STS Temperature	Temperature of static transfer switches is in the allowed limit.
35	Normal Bypass Voltage	Bypass voltage is within defined limits.
36	Normal Bypass Frequency	Bypass frequency is within defined limits.
37	Normal Coil Temperature	UPS inverter or rectifier coil temperature has got back to normal values.
38	Normal Inverter Voltage	Inverter voltage is in the limited values, UPS will switch to normal mode.
39	Normal Load	Output load is under %100, If charging was shut down, it will be activated.
40	BYPASS Thyristor L1	UPS has detected short circuit at bypass L1 thyristor. UPS will shut down.

	Short Circuit	
41	BYPASS Thyristor L2 Short Circuit	UPS has detected short circuit at bypass L2 thyristor. UPS will shut down.
42	BYPASS Thyristor L3 Short Circuit	UPS has detected short circuit at bypass L3 thyristor. UPS will shut down.
43	UPS Thyristor L1 Short Circuit	UPS has detected short circuit at inverter L1 thyristor. UPS will shut down.
44	UPS Thyristor L2 Short Circuit	UPS has detected short circuit at inverter L2 thyristor. UPS will shut down.
45	UPS Thyristor L3 Short Circuit	UPS has detected short circuit at inverter L3 thyristor. UPS will shut down.
46	UPS Thyristor L1 Open Circuit	UPS has detected that inverter L1 thyristor cannot be activated. Load will be transferred to bypass line.
47	UPS Thyristor L2 Open Circuit	UPS has detected that inverter L2 thyristor cannot be activated. Load will be transferred to bypass line.
48	UPS Thyristor L3 Open Circuit	UPS has detected that inverter L3 thyristor cannot be activated. Load will be transferred to bypass line.
49	BYPASS Thyristor L1 Open Circuit	UPS has detected that bypass L1 thyristor cannot be activated. Load will be transferred to inverter line.
50	BYPASS Thyristor L2 Open Circuit	UPS has detected that bypass L2 thyristor cannot be activated. Load will be transferred to inverter line.
51	BYPASS Thyristor L3 Open Circuit	UPS has detected that bypass L3 thyristor cannot be activated. Load will be transferred to inverter line.
52	Parallel System Phase Sequence Error	One or more of UPSs which operate in parallel mode do not match in phase sequence.
53	Battery Start	UPS was given the command to start from the battery.
54	Parallel Start Error	One or more of UPSs which operate in parallel mode could not be prepared to operate.
55	Inverter Error	UPS couldn't prepare the inverter voltage when it was started.
56	Output Off	Static transfer switches all disabled. The loads cannot be energized.
57	Normal Mode	UPS is operating in the normal mode, loads are energized through rectifier – inverter line.
58	Battery Mode	UPS is operating in the battery mode, loads are energized through battery – inverter line.
59	Bypass Mode	UPS is operating in the bypass mode, loads are energized through bypass line.
60	Maintenance Bypass Mode	UPS is operating in the maintenance bypass mode, loads are energized through maintenance bypass line.

61	Parallel Mode	2 or more UPS are operating in power sharing mode. Load is fed through UPSs' inverter lines.
62	Test Mode	UPS has switched to battery test mode, loads are energized through rectifier- battery- inverter line as source sharing.
63	Switch to Inverter Mode	Switching to inverter mode command has been given via front panel.
64	Output Voltage Error	Output voltage is detected during the period of starting UPS. UPS has been stopped.
65	PFC Stop Command	Abnormal situation is detected during the moment of rectifier operating. UPS has given a command to stop itself.
66	Start Command	Start command is given via UPS command menu.
67	Stop Command	Stop command is given via UPS command menu.
68	UPS Stopped	UPS has been stopped.
69	Bypass Error	UPS has switched to bypass mode so many times in a short period, UPS will be shut down.
70	Parameters Changed	Device-related parameters were changed on the service menu.
71	Battery Changed	Battery replacement date has been changed. Battery statistics will be reset.
72	Load Impact Transfer	The load which cannot be handled by inverter is activated. Loads will be transferred to bypass line.
73	Parallel Command	An UPS which is operating in parallel mode has been given a command to change the status of static switches.
74	No Parallel CAN Bus Communication	Slave UPS which is operating in parallel mode can't reach to master UPS from CAN bus. If UPS is operating, will be shut down.
75	Externally Start Command	UPS which is operating in parallel mode has been received a command to start up by another UPS.
76	Externally Stop Command	UPS which is operating in parallel mode has been received a command to stop by another UPS.
77	Externally Switch To BYPASS.	UPS which is operating in parallel mode has been received a command to transfer the load to bypass line.
78	Externally Switch To UPS	UPS which is operating in parallel mode has been received a command to transfer the load to inverter.
79	Parallel Communication FE Error	Slave UPS which is operating in parallel mode has detected a failure of input current sharing.
80	Inverter OKEY	Inverter voltage reached needed value after UPS is started up. UPS can feed the loads through inverter.
81	Abnormal Battery Temperature	Battery temperature is out of defined limits, batteries can be damaged.
82	EPO key pressed	EPO button is pressed.
83	Low Battery	Battery capacity has decreased below defined battery low limit while UPS was operating in battery mode.

84	No Parallel 485 Communication	No RS485 communication between the parallel systems is available.
85	STS Over Current	Time of over load in Bypass line is up.
86	BYPASS Phase Sequence Error	Reverse phase sequence was detected in mains at the UPS run time.
87	Output DC Voltage Error	Inverter DC voltage limit has been exceeded. Loads will be transferred to the bypass line.
88	Output Offset Error	One or more phases of slave devices' output is not connected to master device in parallel systems.
89	Normal Battery Temperature	Battery temperature is within limits.
90	PFC Pbus Over Voltage	Positive bus voltage limit excess.
91	PFC Nbus Over Voltage	Negative bus voltage limit excess.
92	PFC FL1 Over Current	Short circuit protection is activated in rectifier L1 phase.
93	PFC FL2 Over Current	Short circuit protection is activated in rectifier L2 phase.
94	PFC FL3 Over Current	Short circuit protection is activated in rectifier L3 phase.
95	Single Stop	Command to stop itself has been given to UPS which is operating in parallel mode separately from parallel system.
96	Master Changed	UPS became master device in parallel system.
97	Parallel ID Coincidence	ID values of one or more device are the same as each other in parallel system.
98	Stop All	Stop the whole parallel unit command was given via front panel.
99	Power Supply Error	An error signal is detected through power source circuit debugger.
100	Generator Mode	Signal is detected from generator mode input of dry contact board. UPS will switch to generator mode.

6 TABLE of TECHNICAL SPECIFICATIONS

Technical Specifications	
Power	400kVA
Active Power	320 kW
INPUT	
Input Voltage Range	220/380 VAC – 15% + 18% 3P + N + PE
Input Power Factor	At Full Load > 0,99
Input Frequency Range	45-65 Hz (Selectable)
Rectifier	IGBT Rectifier
Total Harmonic Distortion (THDi)	<4%
OUTPUT	
Output Voltage	220/380 VAC 3P + N ± 1% Static, ± 1% Dynamic
Recovery	At 0% - 100% - 0% load maximum output tolerance 5%, 1% back to band<40ms.
Efficiency	Up to 93%.
Output Frequency Range	In 50Hz ±0,5% range synchronous with the network, 50Hz ± 0,2% battery mode
Output Harmonic Distortion (THDv)	Linear Load<2%
	Non-Linear Load <6%
Crest Factor (CF)	3:1
Overload Capacity	At 125 % load 10 minutes, at 150 % load 1 minute.
Protections	The input voltage is out of tolerance, input frequency is out of tolerance, input phase failure, output voltage is out of tolerance, output frequency is out of tolerance, output phase failure, DC component that can occur at the output voltage, Overload that will occur at the output (out of the periods specified), Overheating that will cause failure related to over temperature, high voltage which will occur at DC bus voltage, low voltage which will occur at DC bus voltage, short circuit at the output.
BATTERY	

Quantity (12V DC VRLA)	62 (consists of 2 independent 31 battery groups)
Charge Value (C)	Nominal 0.1 C, selectable.
Battery Power	25% of the device power
COMMUNICATION	
Communication Port	RS232 Standard, RS485 and SNMP Adapter option
Dry Contact	Optional
Protocol	SEC, TELNET
CERTIFICATES	
Quality	ISO 9001
Safety	IEC 62040-1, IEC 60950
EMC	IEC 62040-2
GENERAL	
Running Temperature	0 °C ~40 °C range (for batteries 0 ~ 25 °C)
Storage Temperature	-15 °C ~ 45 °C range (for batteries -10 ~ 60°C)
Protection Class	IP20
Chassis	Anti-Static Paint Protection
Humidity	0-95 %
Operating Altitude	<1000m, Correction Factor 1. <2000m, Correction Factor >0,92, <3000m; Correction Factor >0,84
Logging	500 detailed event log. (Status Menu is recorded)
Parallel Operation	Parallel power increase up to 8 pieces
EPO (Emergency Power Off)	Standard
Isolation Transformer	Optional
Net Weight (Without Battery)	780 kg.
Dimensions (W x D x H)mm	1830x855x2005mm

7 GUARANTEE

7.1 Terms of Guarantee

- Our products are under a two-year guarantee starting from the date of delivery against malfunctions resulting from production, material and workmanship faults. Malfunctions due to such type of faults will be removed without claiming any price of workmanship or spare parts to be replaced.
- Whether aforementioned malfunctions originate from usage faults or not are determined with a report to be issued by service stations, if there exists no service stations, by one of seller, dealer, agency, representative, importer or manufacturer or producer of those products respectively.
- Repair time of defective products is twenty business days at most. This period starts from the date when products are delivered to one of seller, dealer, agency, representative, importer or one of manufacturer or producer. Provided that products break down within the period of guarantee, the time passing during the repair process is added to the guarantee time. Provided that faults of products cannot be removed within ten business days, manufacturer-producer or importer is obliged to assign another product having similar features for the use of consumers until the faulty product has been repaired.
- Even though consumers exercise their repair rights, they can claim free replacement of products, refund or price discount at the rate of fault in the events;
 - That, besides, the product, as of the date when the product is delivered to the consumer, breaks down four times a year or six times within the guarantee period to be determined by the manufacturer-producer and/or importer at least, on the condition of being in guarantee period, such malfunctions perpetuate passing over;
 - That maximum time required for the repair of products is exceeded;
 - That repair of the malfunction is determined as impossible through a report to be issued by service station, if there exists no service station, one of seller, dealer, agency, representative, importer or manufacturer or producer of the company respectively.
- The consumer is, on demand, obliged to submit guarantee certificate in terms of repairs or replacements within the scope of guarantee.
- It is essential that you definitely perform damage control over external packaging before receiving the products to be sent through freight. In the event of any damage, delivery person must be made to prepare a “damage determination record”. (For example; during the delivery process, the product has been checked and seen that is damaged.)

- After the damage determination record has been issued, we request you to inform the MAKELSAN head office of the case. Products to be received from freight by signature means that products have been received completely and without no damage.
- Repairs of plug-and-play products in the places where no service point is around are performed in the factory of MAKELSAN or the nearest service point according to the direction to be made by the MAKELSAN head office. Defective product is delivered by hand to the nearest service point or to the contracted freight company in its original packaging to be sent to the factory of MAKELSAN according to the direction to be made by the MAKELSAN head office. For malfunctions in the scope of guarantee, shipment fees are under the responsibility of MAKELSAN on the condition that products are delivered to the contracted freight company.
- The device must be sent as packed in its original packaging as long as it is not desired by the service. Original packaging of devices should be preserved in order to use them for shipment of devices in terms of repairs to occur. Otherwise, no responsibility is assumed with regards to any troubles to be experienced.
- All defective products to be delivered by hand or through freight are to meet the necessary shipment requirements. (Anti-static protective, bubble wrap or box etc.) It is essential that legible barcode serial number belonging to the product be on the product. Otherwise, it is not covered in the scope of the guarantee.
- It is essential that products to be sent through freight definitely be together with delivery note, and that serial/model/malfunction details be written on delivery note to be sent (for example, breakdown report form), and that packaging content match with the products specified in the delivery note. Otherwise, freight is not accepted.
- The use of the Guarantee Certificate, submitted together with products with MAKELSAN trademark, is permitted by the T.R. Ministry of Industry and Commerce and General Directorate of Protection of Competition with no..... in accordance with the law, with no. 4077, and the notification, with no. TRKGM-95/116-117, issued basing the aforementioned law. MAKELSAN acknowledges and undertakes to obey the liabilities determined by the laws and legislations.

7.2 Cases Not Covered by the Guarantee

- Breakdowns resulting from the use of products contrary to the issues or the environment conditions (temperature, humidity etc.) specified in the user manual are not covered in the scope of guarantee.
- Damages and breakdowns resulting from the use of software, hardware, interface, accessories or consumables apart from those used together with products or recommended ones; changing place, wrong and insufficient maintenance, calibration or use; its operation contrary to environment specifications published for products; insufficiency of air installation; use of products in ambient having excessive humid or temperature; its operation in environment harmful for electrical circuits and abrasive;

and accidents, impacts, electric, shipment, natural disasters, not limited to the ones listed above, are not covered in the scope of product guarantee.

- In the general examination performed during the breakdown acceptance process, certain troubles causing products not to be covered in the scope of guarantee might not be understood. Provided that such faults come up in the detailed examination to be performed via technical service equipment, products are returned to customers.
- Products not covered in the scope of guarantee can, on demand of customer, be treated in a fee-paying way within the bounds of possibilities of the authorized service. Products out of the scope of guarantee, repairs of which are not possible are returned to customers.
- Damages and breakdowns resulting from treatments, internally or externally tampering, efforts to repair and spare part replacement of products, without approval of MAKELSAN, and those resulting from treatment of unauthorized service/dealer/person/establishment, are not covered in the scope of guarantee. Breakdown, cracks, scratches and wear, corrosion and dust to occur in time and by use in the outer surfaces of products (cabinet, cover, and front panel) are not covered in the scope of guarantee.
- In the event that original serial numbers, guarantee labels and stamps on products are removed or distorted, products are not covered in the scope of guarantee. No guarantee is issued against the use of products for any other purpose, apart from those specified in introduction or manual of products.
- Shelf lives of VRLA batteries are 6 months under the ambient temperature of 15 °C and 3 months under the ambient temperature of 25 °C.
- It is compulsory that systems to be purchased be commissioned within 3 months.

MAKELSAN®

Uninterruptible Power Supplies

CERTIFICATE OF GUARANTEE

MANUFACTURER COMPANY

Certificate Approval Date : -- / -- / ----
Certificate No :

TITLE : MAKELSAN MAKİNE KİMYA
ADDRESS : ELEKTRİK SAN. TİC. A.Ş.
TELEPHONE : 0216 – 428 65 80
FAX : 0216 – 327 51 64

SIGNATURE AND STAMP OF
COMPANY AUTHORITY

OF THE PRODUCT

TYPE : _____
TRADEMARK : _____
MODEL : _____
SERIAL NO / BANDEROLE : _____
DELIVERY DATE AND PLACE : _____
MAXIMUM REPAIR PERIOD : 20 business days
GUARANTEE PERIOD : _____

VENDOR

TITLE : _____
ADDRESS : _____
TELEPHONE : _____
FAX : _____
INVOICE DATE / NO : _____
DATE / SIGNATURE AND STAMP : _____

CUSTOMER

TITLE / NAME : _____
ADDRESS : _____
SIGNATURE : _____

UPS AUTHORIZED SERVICES

İstanbul Deri Organize Sanayi
Bölgesi
2. Yol I-5 Parsel
34956 Tuzla/İstanbul
Tel: 0216 428 65 80
Fax: 0216 327 51 64
makelsan@makelsan.com.tr
www.makelsan.com.tr



CERTIFICATE OF GUARANTEE

- 1 – Guarantee period starts from the delivery date of the product and lasts.....years.
- 2 – The whole product, including all its parts are under the guarantee of our company.
- 3 – Provided that the product breaks down within the period of guarantee, the time passing during the repair process is added to the guarantee time. Repair time of the product is business days at most. This period starts from the date when the malfunction related to the product is informed to the service station, if there exists no service station, to one of seller, dealer, agency, representative, importer or one of manufacturer. Provided that the fault of industrial product cannot be removed within 10 business days, manufacturer or importer is obliged to assign another industrial product having similar features for the use of the consumer until the faulty product has been repaired.
- 4 – Provided that the product breaks down due to materials and workmanship or assembly faults within the period of guarantee, the product is repaired without claiming any charge for workmanship, any price for spare part replacement or any fee under any name.
- 5 – The product will be replaced without any charge in the events;
 - That passing over the product perpetuates due to the fact that the product repeats the same malfunction more than twice or different malfunctions occur more than four times in a year starting from the delivery date, on the condition of being in guarantee period;
 - That maximum time required for the repairment of the product is exceeded;
 - That, if there exists no service station, the repair of the malfunction is determined as impossible through a report to be issued one of seller, dealer, agency, representative, importer or manufacturer of the product respectively.
- 6 - Malfunctions resulting from the use of the product contrary to the issues specified in the user manual of the product are not covered in the scope of guarantee.
- 7 –For any trouble that may come up in terms of the Certificate of Guarantee, the Ministry of Industry and Commerce, General Directorate of Protection of Consumer and Competition can be applied.

NOTICE

- 8 – Under no circumstances shall the customer treat the product with the aim of repair, apart from MAKELSAN authorized service personnel.
- 9 – Damages and results originating from the violation of the 8th Article shall be invoiced to the customer.

The use of herein the certificate is permitted by the T.R. Ministry of Industry and Commerce and General Directorate of Protection of Consumers and Competition in accordance with the Law on the Protection of Consumers, with no. 4077, and the Notification Concerning the Application Principles of Guarantee Certificate, issued basing the aforementioned law.

8CONTACT INFORMATION



www.makelsan.com.tr

Headquarter: İstanbul Deri Organize Sanayi Bölgesi 2. Yol I -5 Parsel 34956 Tuzla/ İstanbul

Tel : 0216 428 65 80

Fax : 0216 327 51 64

E-mail : makelsan@makelsan.com.tr

İzmir Office : Halkapınar Mah. 1348 Sok. 2AE Keremoğlu İş Merkezi Yenişehir – İzmir

Tel : 0232 469 47 00

Fax : 0232 449 47 00


E-mail : izmir@makelsan.com.tr

Ankara Office : Mustafa Kemal Mah. 2157 Sok. No:4/6 Çankaya-Ankara

Tel : 0312 219 82 35/37

Fax : 0312 219 82 36

E-mail : ankara@makelsan.com.tr



MAKELSAN®

Uninterruptible Power Supplies

www.makelsan.com.tr

Headquarter: İstanbul Deri Organize Sanayi Bölgesi 2. Yol I -5 Parsel 34956 Tuzla/ İstanbul

Tel : 0216 428 65 80

Fax : 0216 327 51 64

E-mail : makelsan@makelsan.com.tr

İzmir Office : Halkapınar Mah. 1348 Sok. 2AE Keremoğlu İş Merkezi Yenişehir – İzmir

Tel : 0232 469 47 00

Fax : 0232 449 47 00

E-mail : izmir@makelsan.com.tr

Ankara Office : Mustafa Kemal Mah. 2157 Sok. No:4/6 Çankaya-Ankara

Tel : 0312 219 82 35/37

Fax : 0312 219 82 36

E-mail : ankara@makelsan.com.tr