

BlueGuard


hygienic fencing

SINGLE LEAF

Hinged Door

ASSEMBLY INSTRUCTIONS

Door



BlueGuard Single Leaf Sliding Door

ASSEMBLY INSTRUCTIONS

830102 / 830043B
16501015 / 16501025



x 1

4SKBLGHIS

16501040

830042C-F01




x 2

830042C-F02



x 2

830042C-F03




x 2

DIN 1587 M8



x 11

830101 / 830041B
16501010 / 16501020



x 1

4KBLGAGGAC X4

830021



x 8

830026A



x 8

ISO 4017 M8 X 25



x 8

ISO 7093 Ø8 Ø24



x 8

4KBLGBATHIS

830021



x 1

830026A



x 1

830913



x 2

830914



x 1

ISO 4017 M8 X 45




x 2

ISO 7093 Ø8 Ø24



x 2

Tools






13






13

BlueGuard Single Leaf Sliding Door
ASSEMBLY INSTRUCTIONS







BlueGuard Single Leaf Sliding Door

ASSEMBLY INSTRUCTIONS







BlueGuard Single Leaf Sliding Door
ASSEMBLY INSTRUCTIONS







BlueGuard Single Leaf Sliding Door

ASSEMBLY INSTRUCTIONS




BlueGuard Single Leaf Sliding Door

ASSEMBLY INSTRUCTIONS



BlueGuard Single Leaf Sliding Door

ASSEMBLY INSTRUCTIONS - LINEAR



BlueGuard Single Leaf Sliding Door

ASSEMBLY INSTRUCTIONS - ANGULAR 90°

